


URBM22SIWPRY, URBM28SIWPRY ICE MAKER MANUAL:



1. press the switch on/off, Ice maker will be on/off.
2. when the ice maker is on, press the switch for 10 seconds, it will be in manual mode for ice dropping.

Light Instruction:

1. Ice making process: light is on, but it is in respiratory state (gradually darken, then gradually brighten.....)
2. Ice maker off: light is off
3. Ice is full: light is on, in a same brightness
4. The ice tray is not in the right position, Flashing: 0.5second/time (1HZ)

Defective failure:

1. Ice blockage:

Fast Flashing: 200ms/time

Trouble shooting: check the ice tray, there are ice blockage.

2. Error code: 1S

Ice maker failure, Troubleshooting:

1. Check the cable connection
2. Check the ice maker
3. Check the PCB