

UNBOXING AND INSTALLATION

Majestic II

How-To Guide





Overview

Unboxing and installation of the ILVE Majestic II range must be carried out using proper handling and installation procedures to ensure safe operation and optimal performance. This document outlines the required steps for safely unpacking, positioning, and preparing the appliance for installation.



Prior to installation, verify that the model and electrical or gas configuration match the site requirements. Carefully inspect the unit for any shipping damage before proceeding. The range must be installed in accordance with local building codes and manufacturer specifications. Installation should be performed by a qualified and licensed technician.

Additional Resources:

For a full illustrated guide, refer to the ILVE support article:

[How to Unbox and Install ILVE Majestic II Range](#)

Watch the step-by-step video tutorial:

[Unboxing & Installation – ILVE Majestic II Range](#)

Tools & Parts Required

Crowbar

Screwdriver

Pliers

Two people (for safe lifting and positioning)

Cardboard or protective floor padding

Step by Step

- ① Carefully loosen the wooden crate surrounding the range using a crowbar.



- ② With assistance, lift and remove the wooden crate to fully expose the appliance.



- ③ Remove and discard all outer cardboard packaging materials.



- ④ Peel away and remove all protective plastic wrapping from the range body.



Step by Step (cont.)

- ⑤ Remove the cooktop grates and burner caps to prevent shifting or damage during handling.



- ⑥ Pull out the bottom drawer and set it aside in a safe location.



- ⑦ Using a screwdriver or pliers, carefully detach the oven doors to reduce weight for safer handling.



- ⑧ Remove all racks, trays, and accessories from both oven cavities.

Important: Ensure the unit is completely empty before proceeding.



Step by Step (cont.)

- ⑨ Place a piece of the original packaging cardboard on the floor to protect rear floor surfaces while handling or rotating the range.



- ⑩ Ensure a firm and secure grip on the unit before attempting to lift or reposition it.



- ⑪ With assistance from a second person, gently rotate the range onto its side or back to access the bottom panel.



- ⑫ Remove any temporary feet or transport supports attached to the base of the unit.



Step by Step (cont.)

- ⑬ Remove the adjustable legs from the kit and install them according to the provided instructions.



- ⑭ Tighten each adjustable leg securely to ensure proper stability and safe placement of the unit.



- ⑮ Carefully lift the unit and slide the wooden pallet out from beneath the appliance.



- ⑯ Lift the unit carefully and avoid placing full weight on the legs to prevent bending or damage.



Step by Step (cont.)

- ①⑦ Carefully move the range into its final installation position in the kitchen.



- ①⑧ Reinstall the oven doors, drawer, burner caps, and grates to complete the installation.



Final Checks

- Confirm the range is level, the legs are secure, and the unit does not rock.
- Verify electrical and/or gas connections comply with local codes.
- Ensure all removed components are properly reinstalled and seated.
- Restore utilities and test burners and oven operation.

For additional assistance, manuals, or replacement parts, visit us.ilve.com or contact our [support team](#).